

Wearable Device Bluetooth Sniffing

...


Hamza Ahmed, Sid Burre, Preethi Chidambaram, Matthew Whelan

Outline

Can traffic between wearable devices be analyzed to classify and determine wearable activity?

- Background
- Related Work
- Methods
- Results
- Discussion



Background



- Increasing use of bluetooth devices to track activities
 - Smart watches, headphones, in-car systems, smart home devices, health and wellness monitoring
 - Estimated 5.5 billion new devices this year
- Bluetooth Devices can contain sensitive information
 - Credit card info, authentication codes, phone call traffic
- Eavesdropping is a concern

Background: Bluetooth protocol

- Bluetooth Classic (2.4 GHZ)
 - Data-intensive or latency-sensitive situations
- Bluetooth Low Energy (BLE)
 - Optimized for low energy consumption
 - Short connections with high data transfer rates (1+ Mbps)
- Process
 - Master device pairs with one or more slaves
 - Slave communicates in master's piconet
 - Use same frequency hopping pattern





Related Work: Carplay Example

Digital Forensic Case Studies for In-Vehicle Infotainment Systems Using Android Auto and Apple CarPlay

- Analyzed wired and wireless connections between phones and in-vehicle infotainment systems
 - Mobile device uses WiFi or LTE to communicate with cloud server
 - Runs Man in the Middle (MitM) attack
 - Wireless communication uses WiFi and Bluetooth,
 - Collected and analyzed WiFi and BT packets
 - Research used limited configurations
 - Could not analyze encrypted WiFi traffic
- We decided to look deeper into only Bluetooth traffic in different environments

Every Byte Matters Example

- Analyzed traffic generated from various wearable devices to infer sensitive information about the user (such as health status, physical activity, and location)
 - Utilized a commercial wide-band scanner
 - 10,700 Bluetooth captures
- Was able to show great specificity in predicting the devices and actions of users



How do we depart from Every Byte Matters

Approach:

- Single Device
- Small number of “more sensitive” applications
- Focus on **using** application over simply **opening** applications

Applications 20Min, ASB, Alarm, AppInTheAir, AthanPro, AthkarOfPrayer, Battery, BeurerApp, Bild, Bring, Calm, Camera, ChinaDaily, Citymapper, DCLMRadio, DailyTracking, DenverApp, DiabetesM, DuaKhatq-mAlQuran, Endomondo, FITIVApp, FITIVPlus, FindMyPhone, Fit, FitBreathe, FitWorkout, Fitbit, Flashlight, FoursquareCityGuide, Glide, GooglePay, GooglePlayMusic, HealthyRecipes, HeartRate, HuaweiApp, Kaia, KeepNotes, Krone, Lifesum, MapMyFitness, MapMyRun, Maps, Medisafe, Meduza, MiApp, Mobills, Music, MyFitnessPalApp, NYT, NoApp, Outlook, PearApp, **Phone**, PhotoApp, PillReminder, PlayMusic, PlayStore, Qardio, RamadanTime, Reminders, **Running**, SalatTime, SamsungHealthApp, Shazam, Sleep, SleepTracking, SmartZmanim, SmokingLog, **Spotify**, Strava, Telegram, Timer, Translate, Walgreens, WashPost, WearCasts, Weather, **Workout**.

Actions AddCalorie, AddCarbs, AddFat, AddFood, AddGlucose, AddInsulin, AddProteins, AddWater, Browse, BrowseMap, CaloriesAdd, Coffees, EmailReceived, **HeartRate**, Leisure, LiveStream, NightLife, Open, PhoneCallMissed, PhotoTransfer, Play, Restaurants, **Running**, SearchRecipe, Shopping, Skip, **SMSReceived**, Sync, Walking, **Workout**.

Methods: Data Collection

Devices:

- Apple Watch Series 4 with Watch OS 9.3.1
- iPhone 14 Pro with IOS 16.0.2

Data Collection

- Collected in 3 minute segments
- Xcode Packet Logger extension used
- 10 sets of data collected per data type

Tests:


- Phone Call (answered)
- Phone Call (notification)
- Messages
- Duo notification
- ECG Data collection
- Strength Training
- Outdoor walks
- Spotify music playback

Methods: Data Processing and Packet Analysis

Separated Data to only contain L2CAP packets


L2CAP:

- Logical Link Control Adaptation Protocol
- Responsible for segmentation and reassembly of operation data
- Passes packets to the Host Controller Interface (HCI)



The screenshot shows a Wireshark packet capture interface. The top bar includes filters for 'All Devices', 'All Handles', and 'All Packet Types'. Below this, a summary bar indicates '5460 total (0 Err / 0 HCI / 0 ACL / 0 SCO / 0 ISO / 0 Misc)' packets. The main packet list table shows the following entries:

Time	Type	Handle	Addr	Decoded Packet
Apr 05 18:17:38.825	HCI Event			> Vendor Specific Event
Apr 05 18:17:38.858	HCI Event	0x005F	..Watch	> Number Of Completed Packets - Handle: 0x005F - Packets: 0x0001
Apr 05 18:17:38.859	HCI Event			> Vendor Specific Event
Apr 05 18:17:38.882	L2CAP Receive	0x0025	..Watch	> Channel ID: 0x380B Length: 0x0002 (02) [01 22]
Apr 05 18:17:38.882	L2CAP Receive	0x0025	..Watch	> Channel ID: 0x380B Length: 0x0047 (71) [42 22 03 00 40 72 33 C0
Apr 05 18:17:38.885	L2CAP Receive	0x0025	..Watch	> Channel ID: 0x380B Length: 0x0237 (567) [44 22 03 02 30 72 33 80
Apr 05 18:17:38.889	L2CAP Receive	0x005F	..Watch	> Channel ID: 0x3508 Length: 0x0005 (05) [6A 22 14 01 00]
Apr 05 18:17:38.889	HCI Command			> Write Automatic Flush Timeout
Apr 05 18:17:38.889	L2CAP Receive	0x0025	..Watch	> Channel ID: 0x3609 Length: 0x0002 (02) [01 2C]
Apr 05 18:17:38.889	L2CAP Send	0x0025	..Watch	> Channel ID: 0x0B0A Length: 0x0002 (02) [01 21]
Apr 05 18:17:38.889	L2CAP Send	0x0025	..Watch	> Channel ID: 0x0B0A Length: 0x0047 (71) [44 23 03 00 40 72 33 80
Apr 05 18:17:38.889	L2CAP Send	0x0025	..Watch	> Channel ID: 0x0B0A Length: 0x004F (79) [46 23 03 00 48 72 33 82
Apr 05 18:17:38.889	L2CAP Send	0x0025	..Watch	> Channel ID: 0x0B0A Length: 0x025E (602) [48 23 03 02 58 72 33 88





Methods: Machine Learning approach

Goal: Determine the type of data being transferred from packet information


- Feature Extraction - various functions to extract specific stats:
 - deltas - time difference between consecutive packets
 - extract_bins - organizes packet sizes into certain ranges
 - avgIPT - average interpacket time for incoming and outgoing packets
 - stats - obtains min, max, mean, standard deviation of packet sizes and time deltas
- Used different ML models to train and test
 - naive-bayes, svm, knearest neighbors, random forest

Results


- Random forest achieved 78% accuracy
- Naive-bayes achieved 93.75% accuracy
- Extracted feature importance
 - Number of incoming packets had highest importance



Comparison to Every Byte Matters



(a) Classic devices.



(b) LE devices.

Limitations and Extensions

Limitations:

- Collecting sufficient data difficult to train robust model

Future Work:

- Collecting more descriptive data
 - Improve feature importance and prediction accuracy
- Expand to different devices and smartwatches
- Experiment on different types of notification data (different apps)
- Testing every byte matters model on our data
 - Can their model generalize well to new data?
- Deploying our model to consume a stream of data